

- DE -  
- EN -  
- FR -  
- NL -  
- ES -  
- IT -  
- PL -  
- CS -  
- PT -  
- DA -  
- RU -

	A	143 cm
	B	53 cm
	C	120 cm
		53 kg
		0,76 m <sup>2</sup>

	max. 130 kg
---	----------------

		
~30 – 40 Min.		



















Auf 100% Altpapier gedruckt!

Abb. ähnlich

## Montageanleitung Ergometer „RACER S“

Art.-Nr. 07988-727

	1	✓
	1/1	
	1/1	
	1	
	1	
	1	
	1/1	
	1/1	
	1	
	1	
	1	


	1	
	1	
 M16	3	
	1	
 M8 x 60	4	
 Ø 8,3x16x2	4	
 M5 x 10	2	
 M6 x 30	1	
 M6 x 20	4	
 Ø 6,4x10x1,5	4	
 3,9 x 16	1	
 SW 4/5/6	3	
 SW 15	1	
	1	
	2	
	1	

# Ersatzteilbestellung

- EN - Spare parts order
- FR - Commande de pièces de rechange
- NL - Bestelling van reserveonderdelen
- ES - Pedido de recambios

- IT - Ordine di pezzi di ricambio
- PL - Zamówienie części zamiennych
- CS - Objednání náhradních dílů

- PT - Encomenda de peças sobressalentes
- DA - Bestilling af reservedele
- RU - Заказ запчастей



# Ersatzteilbestellung

## 07988-727

### Racer S

①	Lenksäule	1	97004313
②	Führungsschiene u.	1	43001044
③	Führungsschiene o.	1	43001043
④	Endkappe unten	2	70120777
⑤	Endkappe oben	1	70120776
⑥	Untert. f. Lenkeraufn.	1	33200105
⑦	Obert. f. Lenkeraufn.	1	33200106
⑧	Spannschr.	4	11701050
⑨	Untert. Cockpitaufn.	1	70101148
⑩	Obert. Cockpitaufn.	1	70101147
⑪	Lenker	1	91150910
⑫	Abdeckung Obert.	1	70120773
⑬	4967 Führungsteil	2	70111041
⑭	4927 Führungsteil	2	70113924
⑮	Monitor	1	67001400
⑯	Tablethalter	1	94319185
⑰	Abdeckung Untert.	1	70120774
⑱	Schienengelenk unt.	1	97202145
⑲	Schienengelenk obert.	1	97202154
⑳	Le We Kappe	1	70120775
㉑	Schnellspanner	1	33200125
㉒	Schraubsockel	2	10121141
㉓	Gleitfolie	2	43001045
㉔	Führungs Buchse	1	70132059
㉕	Rohrendstopfen H	1	70132062
㉖	Rohrendstopfen V	1	70132061
㉗	Sattelaufn. kompl.	1	33200108
㉘	Sattel	1	72008328
㉙	Antr. Rad	1	91130139
㉚	Seeger Ring	1	10709003
㉛	Kugellager	2	33100040
㉜	Poly V Riemen	1	67005129
㉝	Pedalarm	1	33001030
㉞	Pedale	1	33300015

## 07988-727

### Racer S

③⑧	Spannhebel	1	91140490
③⑨	Zugfeder	1	25635052
④⑩	Gesch. Aufn.	1	67000786
④①	Bremssteuerung	1	67001009
④②	Spule	1	91140489
④③	Distanzblech	2	94503799
④④	Stromkabel 750mm	1	67001021
④⑤	Stromkabel 950mm	1	67001004
④⑥	Stromkabel 1400mm	1	67000926
④⑦	Spannschr.	1	11701051
④⑧	Schwungrad	1	94604727
④⑨	Bodenrohr	1	91112240
⑤⑩	Rolle Skater	2	40814072
⑤①	Rollen Abdeckung	2	70129114
⑤②	Bodenrohr	1	91112241
⑤③	Gegenblech	2	91112015
⑤④	Bodenschoner	1	94600804
⑤⑤	Seitenverkleidung	1	94604724
⑤⑥	Einsatz	1	94600806
⑤⑦	Aufn. Netzsteck.	1	70101161
⑤⑧	Fußrohrabdeckung	1	94604725
⑤⑨	Kunststoffkappe Kurbelarm	2	33001031
⑥⑩	Sattelrohr	1	97004133
⑥①	Sattelklemmring	1	33200104
⑥②	Führungsschlitten	1	9111224
⑥③	Brustgurt	1	07930-610
⑥④	Stromkabel 500mm	2	67001052
⑥⑤	Netzteil	1	42860015
⑥⑥	Trinkflaschenhalter	1	91170790
⑥⑦	Adapterstück	1	94604726
⑥⑧	Schraubenbeutel	1	91180585
⑥⑨	Lenkerband	1	72008330
⑦⑩	Distanzstück	1	97201636

